

# CERAMIC LIQUID VALVES

## OEM

IVEK Ceramic Liquid Valves offer a durable high-performance alternative to “plug valves” commonly used in instrumentation. Traditional plastic valves have a limited life due to material wear and leakage, requiring them to be replaced on a maintenance schedule. IVEK Ceramic Liquid Valves include ceramic rotor and stator components that are inert and offer millions of cycles without wear or degradation of performance. IVEK Ceramic Liquid Valves offer high quality solutions resulting in a total lower cost for the instrument manufacturer. These valves can be used with many of the current Syringe Pumps commercially available. Compared to traditional solenoid valves, IVEK Shear valves do not pump any fluid when moving from position to position.



IVEK Corporation is an ISO 9001 certified manufacturing company specializing in precision fluidic systems based on ceramic technology. IVEK controls all manufacturing and critical ceramic machining operations in-house. Rapid prototyping and free application testing are available when needed.

## FEATURES AND BENEFITS

- chemically inert
- proven to last at least 30 times longer than KEL-F/Teflon plug valves
- reliable operation over a wide range of temperatures
- pressure range from vacuum to 600 PSIG (4137 KPA)
- custom designs available
- available for many current syringe pumps
- ceramic sealing and wetted surface
- materials of construction: 96% aluminum oxide ceramic
- no pumping action when turning
- free application analysis available



**ISO 9001 CERTIFIED**  
**ISO 13485 CERTIFIED**



IVEK CORPORATION • 10 FAIRBANKS ROAD • NORTH SPRINGFIELD • VERMONT • 05150 • USA  
TEL: (01) 802-886-2238 • FAX: (01) 802-886-8274 • TOLL FREE IN NORTH AMERICA: 800-356-4746